

Fabrication of Full Dentures

1. Take **preliminary alginate impressions** being sure to capture all borders and necessary landmarks. (i.e. hamular notch, retromolar pad)
2. Send impression to lab for the fabrication of a **custom tray**. The tray should be made 2mm short of full extension to allow for border moulding. (4 Days)
3. Border mould custom tray appropriately (i.e. compound stick, adaptal) and take **final impression**.
4. Send final impression to lab for the fabrication of a **processed base with wax rim and remount cast**. (5 days)
5. Seat the processed base and rim, verify fit, contour wax accordingly (i.e. horizontal plane, fox plane) and take **bite registration**.
6. Send to lab to complete the trial wax set-up. (6 Days)
7. Try-in the trial wax set-up, verify the bite and aesthetics.
8. Return wax-set up to lab to be processed and finished. (6 Days)
9. Seat finished denture and make any necessary final adjustments.
10. Any resets require additional appointments.



Please note:

We highly recommend the use of Gothic Arch Tracer to find centric for completely edentulous cases. For more information on these, please contact us.

All times include pick-up and delivery.